



DRA260

Skizze	Art.Nr.	Benennung	description
2	390 2202 013	Bügel	cord wrap
6	390 2203 121	Gummifuß	rubber foot
13	390 2202 017	Umlenkrolle	angle
14	390 2202 018	Schraube	screw
17	390 2202 021	Stöpsel	plug
24	390 2203 014	Kettenrad	chain wheel
29	390 2202 140	Buchse	sleeve
40	390 2202 030	Sechskantbolzen	bolt
42	390 2202 149	Kabelklemme	cable clamp
43	390 2202 150	Kabeltülle	rubber buffer
44	390 2202 122	Rippenband	ripped belt
48	390 2202 032	Welle	rod
52-53	8800 2601	Kabelverschraubung M16	cable closing with nut M16
54	390 2202 033	Sechskantmutter	hexagonal nut
58	390 2202 041	Schutzhaube	protection hood
59	390 2203 114	Schalterbox	switch box
61	390 2203 119	Überlastschutz	overcurrent protector
65	390 2203 116	Anschlussklemme	terminal
66	390 2203 011	Schalter	switch
68	0104 7107	Sicherungsscheibe	circlip ring
70	390 2202 047	Kettenrad	chain wheel
71	390 2203 108	Buchse	square sleeve
72	390 2202 049	Zahnrad	gear wheel
74	390 2203 034	Riemenscheibe kpl.	pulley cpl.
75	390 2202 052	Schwenkhebel	wing
76	390 2202 053	Zugfeder	retracting spring
77	390 2203 106	Exzenterbolzen	eccentric shaft
81	390 2203 019	Kettenrad	chain wheel
82	390 2202 058	Rollenkette	chain
86	390 2202 125	Rippenband	ripped belt
91	390 2203 013	Motorriemenscheibe	motor pulley
93	390 2203 027	Kugellager	bearing
94	390 2203 028	Lagerschale	bearing seat
104	390 2203 087	Lagerbuchse	bearing bush
107	390 2203 092	Sperrklinke	ratchet
108	390 2203 030	Schraube	screw
109	390 2203 029	Klemmleiste	blade plate
110	390 2203 701	Hobelmesser	Planing knives
111	390 2203 090	Hobelwelle	cutterhead
111-2	390 2205 005	Hobelwellenachse	cutterblock axle
112	390 2203 026	Einstellschraube	adjusting bolt
113	7137 0023	Nadellager HK1210	needle bearing HK1210
114	390 2205 003	Lagerschale	bearing dish
115	390 2205 002	Leitblech	baffle plate
117	390 2202 083	Zeiger	pointer
122, 122-1, 122-2	390 2205 001	Klemmhalterung kpl.	clamping bracket cpl.
123	390 2202 090	Sterngriffmutter	hand knob
125	390 2202 176	Gewindeschraube M6x40	stud bolt M6x40
126	390 2202 091	Stopfen	cover
127	390 2202 092	Führungsrohr	square tube
127-1	390 2202 093	Stopfen	cover
129	390 2202 094	Sterngriffmutter	hand knob
131	390 2202 095	Endschalter	limit switch
132	390 2202 096	Schaltergehäuse	switch cover
133	390 2202 099	Bundbolzen	stud bolt
134	390 2202 181	Lagergehäuse	bearing cap
177	390 2202 118	Schiebestock	hand spike
178	0109 1105	Inbusschlüssel	hexagon stud wrench
171 - 176 / 176-1	390 2205 004	Spänekanal kpl.	dust collector cpl.